


# CORVUM

## Call Forwarding

You can forward calls to any number.

- In the case of an emergency or internet outage, send calls to a designated failover phone number.
- If you experience bad sound quality due to bad connectivity, send calls to your mobile line.
- When you or a team member goes on holidays.
- If you to take a lunch break, send calls to another person.



### **Failover**

When enabled, if all your devices are unregistered (not active), then the system will automatically call-forward (even if the Enable Call-Forward setting is not enabled)

### **Bypass user's phones**

When enabled, this will prevent your devices (softphones, desk phones) from ringing. Example: if you want to ONLY ring your cellphone (and not your softphone/desk phone) – enable this.

### **Require Key Press**

When enabled, if you receive a call, you will first hear a prompt asking you to "press 1 to accept the call".

*This ensures that Corvum will take the voicemail message, rather than whatever phone the call has been forwarded to.*

### **Keep Caller ID**

When enabled, the caller-ID of the person being forwarded will display. when disabled, the caller-ID of your Corvum account will display.

### **Direct Calls Only**

If enabled, your calls will only be forwarded if you are rung directly and not when rung as a member of a group (ring group, etc...)

# CORVUM

To set up or change the settings of your Call Forwarding, please contact [support@corvum.io](mailto:support@corvum.io)

Once you have selected your desired settings, use Feature Codes to enable and disable Call Forwarding

## Call Forwarding

Enable Call Forwarding	*72
Disable Call Forwarding	*73
Toggle Call Forwarding	*74

After dialing the Feature Code to enable call forwarding, the settings you specified will be immediately applied.

*Note: Disable call forwarding when no longer needed!*

